

SERVICE INSTRUCTION

RUNNING MODIFICATIONS ON

ROTAX® ENGINE TYPE 912/914 (SERIES)

SI-912-020R7

SI-914-022R7

|| This SI revises SI-912-020R6 and SI-914-022R6 dated 03 September 2012.

Symbols used:

Please, pay attention to the following symbols throughout the Service Bulletin emphasizing particular information.

▲ **WARNING:** Identifies an instruction, which if not followed, may cause serious injury or even death.

■ **CAUTION:** Denotes an instruction which if not followed, may severely damage the engine or could lead to suspension of warranty.

◆ **NOTE:** Information useful for better handling.

|| | A revision bar outside of the page margin indicates a change to text or graphic.

1) Planning information

1.1) Engines affected

All versions of the engine type:

- 912 Series all - 912 pre-series engines all
- 914 Series all - 914 pre-series engines all

1.2) Concurrent ASB/SB/SI and SL

none

1.3) Reason

ROTAX® reserves the right to abandon or modify specifications, design, details, models or equipment at any time without obligation.

1.4) Subject

Running modifications on ROTAX® engine type 912/914 (Series).

1.5) Compliance

NONE - For Information Only

▲ **WARNING:** Non-compliance with these instructions could result in engine damage, personal injury or death!

1.6) Approval

The technical content of this document is approved under the authority of DOA Nr. EASA.21J.048.

1.7) References

In addition to this technical information refer to

- current issue of the Operators Manual (OM)
- engine data sheet
- power, torque and fuel consumption curves
- current issue of the Illustrated Parts Catalog (IPC)
- Installation Manual (IM)
- all relevant Alert Service Bulletins (ASB)
- all relevant Service Bulletins (SB)
- all relevant Service Instructions (SI)
- all relevant Service Letters (SL)
- Maintenance Manual (MM)
- Users Guide

d05512

- ◆ NOTE: The status of Manuals can be determined by checking the table of amendments of the Manual. The 1st column of this table is the revision status. Compare this number to that listed on the ROTAX WebSite: www.FLYROTAX.com. Updates and current revisions can be downloaded for free.

2) Material Information

2.1) Material - cost and availability

Price and availability will be supplied on request by ROTAX[®] Authorized Distributors or their Service Center.

2.2) Special tooling/lubricant-/adhesives-/sealing compound -

Price and availability will be supplied on request by ROTAX[®] Authorized Distributors or their Service Center.

3) Accomplishment / Instructions

- ◆ NOTE: Before maintenance, review the entire documentation to make sure you have a complete understanding of the procedure and requirements to prevent mistakes from an incomplete review of all of the information in this document.

All the measures must be taken and confirmed by the following persons or facilities:

- ROTAX[®] -Distributors or their Service Center
- Persons with the respective Aviation Authority

▲ WARNING: Proceed with this work only in a non-smoking area and not close to sparks or open flames. Switch off ignition and secure engine against unintentional operation. Secure aircraft against unauthorized operation. Disconnect negative terminal of aircraft battery.

▲ WARNING: Risk of scalds and burns! Allow engine to cool sufficiently and use appropriate safety gear while performing work.

▲ WARNING: Should removal of a locking device (namely lock tabs, self-locking fasteners) be required when undergoing disassembly/assembly, always replace with a new one.

- ◆ NOTE: All work has to be performed in accordance with the relevant Maintenance Manual.

- ◆ NOTE: The illustrations in this document show the typical construction. They may not represent full detail or the exact shape of the parts which have the same or similar function.
Exploded views are **no technical** drawings and are for reference only. For specific detail, refer to the current documents of the respective engine type.

Approval of translation to best knowledge and judgement - in any case the original text in German language and the metric units (SI-system) are authoritative.

4) Documentation

4.1) List of the valid pages

	Chapter	Page	Date		Chapter	Page	Date		Chapter	Page	Date
	00-00-00	1	05 15 2013			7	05 15 2013			3	04 15 2008
		2	09 03 2012			8	05 15 2013			4	04 15 2008
		3	05 15 2013			9	05 15 2013		76-00-00	1	11 03 2008
		4	04 15 2008			10	05 15 2013			2	11 03 2008
	72-00-00	1	05 15 2013			11	05 15 2013			3	11 03 2008
		2	05 15 2013			12	05 15 2013			4	11 03 2008
		3	05 15 2013			13	05 15 2013		78-00-00	1	05 28 2010
		4	05 15 2013			14	05 15 2013			2	04 15 2008
	73-00-00	1	04 15 2008		74-00-00	1	05 28 2010		79-00-00	1	09 03 2012
		2	04 15 2008			2	05 28 2010			2	09 03 2012
		3	04 15 2008			3	11 24 2010			3	09 03 2012
		4	05 15 2013			4	05 15 2013			4	09 03 2012
		5	07 28 2008		75-00-00	1	04 15 2008			5	09 03 2012
		6	05 15 2013			2	04 15 2008			6	09 03 2012

4.2) Table of amendments

Approval*

The technical content of this document is approved
under the authority of DOA ref. EASA.21J.048.

NOTES

SECTION 72-00-00

1) Introduction of new cylinder heads part no. 413235/413245/413185/413195 for ROTAX® 912/14 Series

1.1) General Information

(see fig. 1)

In the course of continuous development and standardization with ROTAX® 912 iS new cylinder heads with modification has been introduced.

The new cylinder heads has been already installed on the following engines:

- 912 A up to S/N 4,410.982 inclusive
- 912 F up to S/N 4,413.020 inclusive
- 912 S up to S/N 4,924.544 inclusive
- 912 UL up to S/N 6,770.937 inclusive
- 912 ULS up to S/N 6,781.410 inclusive
- 914 F up to S/N 4,421.178 inclusive
- 914 UL up to S/N 7,682.718 inclusive

parts requirement:

Fig item no	New part no	Qty per engine	Description	Old part no	application
	413235	1	cylinder head 2/3 assy.	623682	cylinder head
	413245	1	cylinder head 1/4 assy.	623692	cylinder head
	413185	1	cylinder head 2/3 assy.	623687	cylinder head
	413195	1	cylinder head 1/4 assy.	623697	cylinder head

- ◆ NOTE: It is not mandatory to retrofit engines with the old cylinder heads!
Different visions of cylinder heads may be intermixed.

In case of a retrofitting/repair or overhaul, observed the installation and maintenance related changes, since specifically changes in the cylinder head temperature sensor position and thus a change of the wiring is necessary. Proof of certification to the latest requirements such as FAR or EASA has to be supplied by the aircraft manufacturer.

1.2) Changes concerning installation

(see fig. 1)

See latest Installation Manual for the related engine type.

Regarding change of position see fig. 1.

- ◆ NOTE: The temperature sensor part no. 965531, its connection and the operating limits of the cylinder head temperature are unchanged.

1.3) Changes concerning maintenance (cylinder head 2/3 assy.)

(see fig.1 and fig. 2)

See latest Maintenance Manual (Heavy).

- ◆ NOTE: Contrary to the current design, the temperature sensor is directly flooded with coolant. Therefore the thread must be sealed with LOCTITE.

The following changes concerning maintenance must be observed:

1. Clean the thread of the temperature sensor.
2. Apply LOCTITE 243 to the thread of the temperature sensor. Tightening torque 10 Nm (90 in.lb).
3. Plug the respective wiring harness connector into the temperature sensor.

1.4) Illustration

the following drawings should convey additional information:

d05513

MAY 15th 2013
Initial Issue


Current valid documentation see:
www.FLYROTAX.com

SI-912-020
SI-914-022

72-00-00

page 1 of 4

Cylinder 2/3



2) Change of the tightening torque procedure for the installation of the cylinder heads

2.1) General Information

In the course of continuous development a new tightening torque procedure for the installation of the cylinder heads has been introduced.

This new procedure has already been incorporated on the following engines:

- 912 A up to S/N 4,410.977 inclusive
- 912 F up to S/N 4,413.018 inclusive
- 912 S up to S/N 4,924.497 inclusive
- 912 UL up to S/N 6,770.893 inclusive
- 912 ULS up to S/N 6,781.191 inclusive
- 914 F up to S/N 4,421.170 inclusive
- 914 UL up to S/N 7,682.596 inclusive

◆ NOTE: This tightening torque procedure must be observed in any maintenance event.

2.2) Installation of the cylinder head

See latest Maintenance Manual (Heavy).

The following changes concerning maintenance must be observed:


1. Fasten the cylinder finger-tight and diagonally at first with M8 collar cap nuts and M8 hex. nuts.
2. Fasten the cylinder heads according to the diagonal torque pattern show in fig. 2.

Tightening torque 10 Nm (90 in.lb) + 120°.

2.3) Illustration

the following drawings should convey additional information:

torque sequence diagram



06472

fig. 2

NOTES

SECTION 73-00-00

1) Introduction of a new flexible fuel line assy. part no. 874911 for ROTAX® 912 Series

1.1) General Information

(see fig. 1 and fig. 2)

In the course of continuous development and for better assembly and maintenance a new flexible fuel line (part no. 874911) has been introduced.

Installation of this new fuel line requires the following modifications:

- mechanical machining at the intake manifold for the attachment of the cable clamp. At engine repair/general overhaul be aware that the fixation of the flexible fuel line needs an appropriate contact surface. If necessary replace the intake manifold or machine the contact surface according to the following instruction.

The new fuel line has been already installed on the following engines:

- 912 A as of S/N 4,410.713
- 912 F as of S/N 4,412.923
- 912 S as of S/N 4,923.384
- 912 UL^{*)} as of S/N 4,408.199
- 912 ULS^{*)} as of S/N 5,647.489
- 912 ULSFR^{*)} as of S/N 4,430.445

^{*)} optional installation possible

parts requirement:

Fig item no	New part no	Qty per engine	Description	Old part no	application
1	874911	1	fuel line assy.	874294	912
2	940872	2	banjo bolt M8x1x24	-	flexible fuel line
3	847795	2	spacer 8.4/12/7.5	-	flexible fuel line
4	950141	6	sealing ring A8x13	-	banjo bolt
5	651430	2	cable clamp 12/M8	-	flexible fuel line
6	940481	2	hex. screw M8X30	240276	carburetor socket
8	942671	2	hex. nut M8	-	cable clamp
9	866719	2	tie wrap 550x8.0	-	flexible fuel line
10	950143	3	gasket ring 8.2/13/1.4	-	banjo bolt/ clamp block

◆ NOTE: It is not mandatory to retrofit engines with the old stainless steel fuel line!

For a retrofit to a flexible fuel line system the following new parts are required:

parts requirement:

Fig item no	New part no	Qty per engine	Description	Old part no	application
	881980	1	flex. fuel line retrofit kit		retrofitting flexible fuel line
consisting of:					
	874911	1	fuel line assy.	874294	912
	940872	2	banjo bolt M8x1x24	-	flexible fuel line
	847795	2	spacer 8.4/12/7.5	-	flexible fuel line
	950141	6	sealing ring A 8x13	-	banjo bolt
	651430	2	cable clamp 12/M8	-	flexible fuel line
	940481	2	hex. screw M8X30	240276	carburetor socket
	942671	2	hex. nut M8	-	cable clamp
	866719	2	tie wrap 550x8.0	-	flexible fuel line
	950143	5	gasket ring 8.2/13/1.4	-	banjo bolt/ clamp block
	851325	1	clamp block - 912	-	clamp block
	230150	1	gasket ring 10x14	-	clamp block
	641733	1	plug screw M10x1x8	-	clamp block
	840518	1	hex. screw M5x18	-	clamp block
	941785	1	banjo bolt assy.	-	clamp block

APRIL 15th, 2008

Initial Issue

Copyright - ROTAX®

SI-912-020

SI-914-022

73-00-00

page 1 of 14

d05514

956312	1	ring hose nipple	-	return line
250311	2	washer 8.4	-	carburetor socket

- Install the flexible fuel line (1) with the double ring hose nipple (13) and sealing ring (10) on the clamp block (11). Tightening torque of banjo screw (14) 10 Nm (90 in. lb.) (see fig. 1).
- Install the ring hose nipple (15) with distance sleeve (3) and sealing ring (4) on the carburetors. Tightening torque of banjo screw (2) 10 Nm (90 in. lb.)


◆ **NOTE:** In case of a retrofit on configurations with steel fuel lines remove the screw connectors (12) and remove remaining sealant residues in a way that they do not get into the carburetor or the fuel system.

- For installation on an old style intake manifold perform the following: Remove the intake manifold and machine the nut/clamp contact area until the surface is parallel with the sealing surface of the carb socket. The thickness of the material must not be dressed down less than 10,5 mm (0.413 in.) and should be smooth and flat so that the nut/clamp assembly has an even contact surface (see fig. 2).
- Ensure proper support of the flexible fuel line. Install Hex. screw (6) and washer (7) with 15 Nm (133 in. lb.). Install the cable clamp (5) at the hex. screw (6) of the carburetor socket with the hex. nut (8). Tightening torque of hex. nut (8) 24 Nm (213 in. lb.)

■ **CAUTION:** While tightening hex. nut (8), hold hex. screw (6) with a wrench to prevent it from loosening. Always fix the flexible fuel line at the compensation tube with clamps (9) in such a way that no wear is possible.

1.2) Illustration

the following drawings should convey additional information:



2) Introduction of a new gasket part no. 950226 for fuel pump ROTAX® 912 Series

2.1) General Information

(see fig.1)

In the course of continuous development a new gasket (1) (part no. 950226) has been introduced.

The new gasket has been already installed on the following engines:

- 912 A as of S/N 4,410.744
- 912 F as of S/N 4,412.929
- 912 S as of S/N 4,923.486
- 912 UL as of S/N 4,408.421
- 912 ULS as of S/N 5,648.605
- 912 ULSFR as of S/N 6,374.096

The new gasket has been already included in all fuel pumps delivered as spare part:

- fuel pump as of S/N 07.002119

parts requirement:

Fig item no	New part no	Qty per engine	Description	Old part no	application
1	950226	1	gasket	950225	fuel pump


The gasket is interchangeable.

2.2) Illustration

the following drawings should convey additional information:

- ◆ NOTE: On the sealing surfaces of the gearbox housing and the fuel pump no sealing compound has to be used.

⚠ B LOCTITE 243



08353
fig. 1

3) Introduction of a new compensation tube part no. 924541 for ROTAX® 912/914 Serie

3.1) General Information

(see fig. 1 and 2)

In the course of continuous development a new compensation tube (1) (part no. 924541) has been introduced which the synchronization to make it easier, the tube must not removed.

In this connection the following modifications became necessary:

- position of connection fitting (3) on compensation tube remains approximate constant
- additional screw (2) part no. 940980 for connection fitting (3)
- new tube (4) part no. 956143 (5) part no. 956141

The new compensation tube has been already installed on the following engines:

- 912 A as of S/N 4,410.807
- 912 F as of S/N 4,412.949
- 912 S as of S/N 4,923.676
- 912 UL as of S/N 4,409.113
- 912 ULS as of S/N 5,650.899
- 914 F as of S/N 4,420.807
- 914 UL as of S/N 6,772.763

parts requirement:

Fig item no.	New part no.	Qty per engine	Description	Old part no.	application
	924541	1	compensation tube assy.	924540	intake manifold
	*)	1	tube 81 mm (3.2 in.)	-	compensation tube
		1	tube 66 mm (2.6 in.)	-	compensation tube

*) in a roll tube part no. 956140

◆ **NOTE:** In case of interchangeable it is not possible to exchange individual parts. The new compensation tube are only **together** interchangeable with the tube part no. 956141. In case of spare parts the relevant configurations must be observed.

Special tools:

Item no.	New part no.	Qty.	Description	Old part no.	Application
		1	hose clamping pliers ^{*)}		tube
		1	hose nipple	940557	intake manifold
		1	sealing ring 6.2/8.9/1	830890	intake manifold

^{*)} e.g. HAZET® mean size or equivalent. See fig. 2.

Pneumatic synchronization:

(see fig. 2)

The two carburetors are adjusted to equal flow rate (mechanical or pneumatical synchronisation) has to be performed in accordance with the relevant Maintenance Manual ROTAX® 912/914 and following changes must be observed:

additional variant (taking advantage of the new compensation tube):

1. Install the vacuum gauge.
2. Clamp the tube with hose clamping pliers (6). Observe the position! The tube (1) must not removed.
3. Unscrew the screw (7).
4. Install the hose nipple M6 (8) with the sealing ring (9).
5. After synchronization tightened the screw M6x6 (7) with LOCTITE 221.

Monitoring of the intake manifold pressure:

The monitoring of the intake manifold pressure has to be performed in accordance with the relevant Installation Manual ROTAX® 912/914 and following changes must be observed:

1. Unscrew the screw (2) from the connecting fitting (3) for indicating instrument.

◆ **NOTE:** If it is not possible to stabilize the intake manifold pressure, tighten the screw M3.5x6 (2) with LOCTITE 221. Install color markings on the screw.


3.2) Illustration

the following drawings should convey additional information:


compensation tube **part no. 924540**

08371

fig. 1





compensation tube **part no. 924541**




- 1 compensation tube
- 2 screw M3.5x6
- 3 connection fitting
- 4, 5 tube
- 6 hose clamp pliers
- 7 hex. screw M6x6
- 8 hose nipple M6
- 9 sealing ring 6.2/8.9/1

⏻ A LOCTITE 221



08449

fig. 2



4. Introduction of a new fuel pump assy. part no. 893115 for ROTAX® 912 Series

4.1) General Information

(see fig. 1 to fig. 7)

In the course of continuous development a fuel pump assy. (part no. 893110 and/or part no. 893114) has been already introduced.

The fuel pump assy. part no. 893110 and part no. 893114 has been already installed on the following engines:

- 912 A from of S/N 4,410.906
- 912 F from of S/N 4,412.990
- 912 S from of S/N 4,924.185
- 912 UL from of S/N 6,770.279
- 912 ULS from of S/N 6,778.296

In the course of standardization a new "basic" fuel pump assy. (part no. 893115) has been introduced, which can be configured with the appropriate nipples or fuel hoses.

The new fuel pump assy. part no. 893115 has already been installed on the following engines:

- 912 A from of S/N 4,410.977 inclusive
- 912 F from of S/N 4,413.018 inclusive
- 912 S from of S/N 4,924.497 inclusive
- 912 UL from of S/N 6,770.893 inclusive
- 912 ULS from of S/N 6,781.191 inclusive

parts requirement:

Fig item no	New part no	Qty per engine	Description	Old part no	application
-	893115	1	fuel pump assy.	892546	912 with isolating flange (gasket) and O-ring
-	950228	1	isolating flange (gasket)	-	fuel pump assy.
-	631870	1	O-ring	-	fuel pump assy.
-	874337	1	fuel hose assy.	-	fuel pump assy. (fuel outlet)
-	874347	1	fuel hose assy.	-	fuel pump assy. (fuel inlet)
-	250425	2	gasket ring 10.2/15/1.5	-	fuel pump assy.
-	840740	1	nipple 7/3.8	-	fuel pump assy. (fuel outlet)
-	840745	1	nipple 9/5.7	-	fuel pump assy. (fuel inlet)
-	840770	1	adapter AN-5 (9/16 UNF)/M10x1	-	fuel pump assy. (fuel inlet)
-	840775	1	adapter AN-6 (1/2 UNF)/M10x1	-	fuel pump assy. (fuel outlet)
-	942674	2	hex. nut M8	-	fuel pump assy.
-	-	2	lock washer A8	945752	fuel pump assy.

◆ NOTE: In case of an upgrade the parts listed above have to be used, the fuel pump must be installed using the new isolating flange (gasket). Amendments concerning service or installation need to be adhered to. Proof of certification to the latest requirements such as FAR or EASA has to be supplied by the aircraft manufacturer.

◆ NOTE: Through this configurability the two fuel pumps (part no. 893110 and part no. 893114) are no longer available and can be composed of the following parts.

Fuel pump part no. 893110 include following parts:		
Part no.	Qty	Description
893115	1	fuel pump assy.
950228	1	isolating flange
631870	1	O-ring
840740	1	nippel 7/3.8 (pump outlet)
840745	1	nippel 9/5.7 (pump inlet)
250425	2	gasket ring 10.2/15/1.5

Fuel pump part no. 893114 include following parts:		
Part no.	Qty.	Description
893115	1	fuel pump assy.
950228	1	isolating flange
631870	1	O-ring
874337	1	fuel hose
874347	1	fuel hose
250425	2	gasket ring 10.2/15/1.5
840770	1	adapter AN-5 (9/18 UNF)/M10x1 (pressure hose)
840775	1	adapter AN-6 (1/2-20 UNF)/M10x1 (suction hose)

4.2) Retrofit of fuel pump assy. part no. 893110 to part no. 893115

(see fig. 1)

Connecting to fuel pump:


Pump inlet (3):

nipple..... 9/5.7
tightening torque..... 10 Nm (90 in.lb)

Pump outlet (2):

nipple 7/3.8
tightening torque..... 10 Nm (90 in.lb)

B LOCTITE 243



4.3) Retrofit of fuel pump assy. part no. 893114 to part no. 893115

(see fig. 2)

Connecting to fuel pump:

Pump inlet (3):

adapter AN-6 (1/2-20 UNF)/M10x1

tightening torque..... 10 Nm (90 in.lb)

Pump outlet (2):

adapter..... AN-5 (9/16-18 UNF)/M10x1

tightening torque..... 10 Nm (90 in.lb)

Connecting fuel hoses to adapter:

Pump inlet (4):

fuel hose assy.AN-6 connection


tightening torque..... 32 Nm (23.6 ft.lb)

Pump outlet (5):

fuel hose assy.AN-5 connection


tightening torque..... 27 Nm (20 ft.lb)

■ CAUTION: Counterhold the adapter during tightening.



Detail:

Lubricate with grease to the
adapter thread



4.4) Changes concerning installation

(see fig. 3 and fig. 4)

Operating limits

See latest Operators Manual.

Fuel pressure:

max.....0.5 bar (7.26 psi)*

min.....0.15 bar (2.2 psi)

* only applicable for fuel pump part no. 893110, part no. 893114 and part no. 893115.

◆ NOTE: In case of an engine replacement or retrofitting it is important to adjust the operating limits of the instrument.

Proof of certification to the latest requirements such as FAR or EASA has to be supplied by the aircraft manufacturer. For more information and related instruction contact the aircraft and/or airframe manufacturer.

Option 1

Connecting to fuel pump (1) with push-on fittings. See fig. 3.

Pump inlet (2):

outside dia..... 8 mm (0.31 in.)

slip-on length for hose attachment: max. 22 mm (0.87 in.)

Pump outlet (3):

outside dia..... 6 mm (0.25 in.)

slip-on length for hose attachment: max. 22 mm (0.87 in.)

Drainage (4):

outside dia..... 6 mm (0.25 in.)

slip-on length for hose attachment: max. 22 mm (0.87 in.)

■ CAUTION: When mounting the fuel line to the fuel pump make sure that the fuel pump is not exposed to excessive force.

■ CAUTION: Use the maximal possible slip-on length for mounting hose. Secure with appropriate hose clamps. Route the lines without kinks and avoid tight bends.

Option 2

Connecting to fuel pump (1) with attached hoses on the fuel hose. See fig. 4.

Pump inlet (2):

thread (5)..... AN5-(9/16-18 UNF)

tightening torque: 15 Nm (135 in.lb)

Pump outlet (3):

ring hose nipple/fitting (6)..... 3/4 DIN 7642

tightening torque: 15 Nm (135 in.lb)

Drainage (4):

outside dia..... 6 mm (0.25 in.)

slip-on length for hose attachment: max. 22 mm (0.87 in.)

■ CAUTION: Route the lines without kinks and avoid tight bends.

■ CAUTION: Drainage line have to be routed into a ram-air and vacuum free zone, according to the requirements and release of BRP-Powertrain. The drainage line must not be routed into the slipstream. Ram pressure or vacuum impair the fuel pressure.

- The drainage line has to be installed in such a way that the excessive fuel/oil flows off.

- The installed drainage line must have a continuous slope downwards.

- The drainage line must be protected against any kind of blockage (e.g. formation of ice).

■ CAUTION: If a auxiliary electrical fuel pump is used a check valve (part no. 874532) should be used. The check valve must have a low cracking pressure and must be installed in a parallel circuit as per the Installation Manual 912/914 Series.

■ CAUTION: Use the pilot jet (part no. 963820) of the fuel pressure line to the fuel return line. See latest Installation Manual 912/914 Series.

4.5) Changes concerning maintenance

(see fig. 3 to fig. 5)

4.5.1) Maintenance checks

See latest Maintenance Manual (Line), maintenance checklist.

- Due to manufacturer specification of the fuel pump, fuel pump must be replaced every 5 years.

■ CAUTION: The 5 year limitation is applicable to all mechanical fuel pumps (Corona, Pierburg and Bing).

- Besides inspection of the fuel lines also the drainage hose (12) (if applicable) must be inspected - check all hoses for damage, leakage, hardening by heat, porosity, loose fittings, secure mounting and sharp bends.

4.5.2) Removal of the fuel pump

See latest Maintenance Manual (Heavy).

■ CAUTION: Replace the isolating flange (gasket) on reinstallation of the fuel pump. It is also required to replace the O-ring at every installation.

4.5.3) Inspection of the fuel pump

See latest Maintenance Manual (Heavy).

■ CAUTION: The fuel pump cover (11) must not be opened. The safety marks has to be intact.

■ CAUTION: The connecting fittings (2,3) must be checked for secure mounting and leakage. If the fittings or the fuel hoses (13,14) have to be removed, clean and reinstall with new gasket ring and LOCTITE 243 and a tightening torque of 10 Nm (90 in.lb).

Fuel pressure

The fuel pressure must not exceed max. 0.5 bar (7.26 psi). The pressure and functional efficiency of the fuel system can be checked with the new fuel pressure gauge kit part no. 874234 or equivalent calibrates test gauge.

■ CAUTION: The fuel pressure gauge kits part no. 874231/ 874233 shows the minimum and maximum allowable fuel pressure. At the new fuel pressure gauge kit part no. 874231 this limits have been adjusted accordingly to 0.15 bar (2.2 psi) to 0.5 bar (7.26 psi).

4.5.4) Installation of the fuel pump

See latest Maintenance Manual (Heavy).

■ CAUTION: It is necessary to use a new insulating flange (gasket) and a new O-ring. Do not reuse the old isolating flange or the old O-ring.

◆ NOTE: On the mating surfaces of the gearbox housing and the fuel pump flange no sealant is necessary.

Install fuel pump with new insulating flange (7) and O-ring (8). Secure and tighten equally the hex screw-nuts M8 (9) with lock washer A8 (10) using LOCTITE 243 - apply a torque of 15 Nm (135 in.lb).


◆ NOTE: LOCTITE 243 has to be re-applied on each (re-)assembly of the fuel pump.

Reconnect fuel lines.

Conduct test run including ignition check and leakage test.


4.6) Appendix

the following drawings should convey additional information



08829
fig. 3


08831
fig. 4



08830
fig. 5

B LOCTITE 243



- | | | | |
|----|----------------------------------|----|-------------------------|
| 1 | fuel pump | 11 | fuel pump cover |
| 2 | connecting fitting (fuel inlet) | 12 | drainage hose |
| 3 | connecting fitting (fuel outlet) | 13 | fuel hose (fuel outlet) |
| 4 | drainage | 14 | fuel hose (fuel inlet) |
| 5 | thread | | |
| 6 | ring hose nipple/fitting | | |
| 7 | insulating flange (gasket) | | |
| 8 | O-ring | | |
| 9 | hex nut M8 | | |
| 10 | lock washer A8 | | |



08828

fig. 6

Dimensions without tolerance ± 0.012 in.



08828

fig. 7

MAY 15th 2013

Copyright - BRP-Powertrain GmbH & CO KG. All rights reserved.

SI-912-020 R7

SI-914-022 R7

73-00-00

page 13 of 14||

NOTES

SECTION 74-00-00

1.) Introduction of a advanced start module (easy starting device for the electronic module)

1.1) General Information

(see fig. 1 and 2)

In the course of further development and standardization an electronic module for delayed start up ignition timing has been introduced. This module can be activated by a 12 V signal. Without this optional 12V activation the function works the same way as on the well-proven previous module.

In this context the following needs to be considered:

- 1 wire of each module circuit A and circuit B (6-pole) to start relay control signal wire (see position 26 in fig. 1) must be supplied by the aircraft manufacturer. Therefore the rubber plug of the pin terminal must be removed before!
- Time factor for delaying ignition timing at start until switching to advanced ignition: After starting the engine and as soon as the starter/relay is not powered anymore, the engine continues to further run for 3-8 seconds with delayed ignition.
- Do not connect the signal wire to the electric starter motor - as the circuit has not voltage protection.
- Do not power the advanced start terminal permanently with 12V. The delay timer function would be bypassed and charging speed might vary (depending on internal tolerances, trigger gap etc.).

The new electronic modules with a starting device have been already installed on the following engines:

- 912 S as of S/N 4,923.847
- 912 ULS as of S/N 6,775.360
- 912 ULSFR as of S/N 6,775.360

List of part no.:

Item no.	New part no.	Qty.	Description	Old part no.	Application
	966872	1	fly wheel hub	966871	ignition system
	881280	1	soft start port		ignition system
consisting of:					
	966727	2	SMD electronic module	966726	ignition system
	827800	1	disc A 5.5		ignition system
	240186	2	allen screw M5x25		ignition system
	945750	1	lock washer A5		ignition system
	260130	2	cable grommet		ignition system
	265275	2	faston connector		ignition system

- ◆ NOTE: Engines having an ignition system which is already equipped with the new 6-pin connectors can be upgraded with both the new module and the new fly wheel hub. Older engines (not having 6-pin connectors) can only be upgraded with the new fly wheel hub. As a retrofit would require considerable changes concerning the wiring.

Technical background information:

Differences between electronic module part no. 966726 and part no. 966727:

		<u>current 966726</u>	<u>new 966727</u>
	<u>fly wheel hub</u>		
ignition point at start	966871 current	4° Before T.D.C.	4° Before T.D.C.
	966872 new	3° After T.D.C.	3° After T.D.C.
time delay for ignition at start:		none	3 - 8 sec.
Switching to advanced ignition:		from 650 to 1000 RPM depending on trigger gap	after the expiration of the time delay (3-8 sec.)
ignition timing in normal operation:		26° before T.D.C.	26° before T.D.C.


d05515

Installation:

- see latest Maintenance Manual (Heavy).


1.2) Illustration

the following drawings should convey additional information:



08684

fig. 1




B	battery	15	2 ignition switches
M	engine	16	master switch
S	signal	17	starter button
1	2 electronic modules (A and B)	18	control lamp
2-3	plug connection for ignition switch	19	battery relay
4	integrated generator	20	battery
5-6	external regulator - rectifier with plug connections	21	bus bar
7	electric starter	22	capacitor
8-9	starter relay with plug connection	23	plug connection for trigger coil assy.
10-12	external alternator with connections	24	trigger coil assy. (tachometer)
13	electric rev counter	25	electric fuel pump
14	capacitor	26	starting equipment at the electronic modules

Wiring symbols to DIN 40712, 40713, 40716 and 40719

08673

08673

fig. 2



08685

fig. 3

SECTION 75-00-00

1.) Introduction of a new expansion tank assy.

1.1) General Information

(see fig 1, 2 and 3)

In the course of further development and standardization the position of the expansion tank (1) has been optimized!

In this connection the following modifications became necessary:

- position of connection (2) to overflow bottle (from 0° to 30±3°)
- position of connection (3) to radiator (from 51° to 27±3°)
- angle of inlet socket (4) from cylinder 4 (34° inclined)
- length of inlet socket (5) from cylinder 3 (length increased by 13,4±3 mm)
- length of coolant hose (6) from cylinder 1 (length increased from 270 mm to 285 mm)
- length of coolant hose (7) from cylinder 4 (shortened from 100 mm to 85 mm)
- new spring type hose clamps (8) to attach the coolant hoses (expansion tank and water pump)

The new expansion tank and the new type of hose clamps have been already installed on the following engines:

- 912 A as of S/N 4,410.419
- 912 F as of S/N 4,412.808
- 912 S as of S/N 4,922.606
- 912 UL as of S/N 4,404.020
- 912 ULS as of S/N 4,426.395
- 912 ULSFR as of S/N 4,429.589
- 914 F as of S/N 4,420.235
- 914 UL as of S/N 4,417.949

List of part no.:

Item no.	New part no.	Qty.	Description	Old part no.	Application
1	922665	1	expansion tank assy.	922398	cooling system
8	851640	16	spring type clamp	251875	cooling system
6	*)	1	coolant hose 285 mm	922542	cylinder 1
7	*)	1	coolant hose 85 mm	922541	cylinder 4

*) water hose in meters part no. 922250.

◆ NOTE: Engines equipped with the old expansion tank, old hose clamps and coolant hoses of old length do not have to be retro fitted with the new equipment!

At engine repair/general overhaul be aware that because of the small distance of the tubes (between cylinder 1 and 3) the spring type hose clamps can not be fitted on the expansion tank part no. 922398.

Due to the different inlet and outlet positions on the expansion tanks, hoses of different length are required. Always verify correct hose length and slip-on length.

Special tools:

Item no.	New part no.	Qty.	Description	Old part no.	Application
	877840	1	spring clamp pliers*)		spring type clamp

*) e.g. HAZET®, BERNER® or equivalent. See fig. 3.

Assembly:

- Inspect the rubber plate (10).

◆ NOTE: Wear of up to 1 mm from original thickness can be tolerated!


d02674

- Install the coolant hose (6) 285 mm to cylinder 1 and the new coolant hose (7) 85 mm to cylinder 4. For attaching all the coolant hoses from expansion tank, water pump, cylinders, use the new spring type clamps.

■ **CAUTION:** Take care of appropriate slip-on length of the coolant hoses on the corresponding connection socket. Verify tight fit of clamps and hoses and check for leakage. Always fit the clamps such that they can not wear on any component and use a suitable tool (see fig. 3) for fitting them.

1.2) Illustration

the following drawings should convey additional information:







fig. 2



08380

fig. 3

NOTES

SECTION 76-00-00

1.) Introduction of a new 3-way solenoid valve part no. 874313 for ROTAX® 914 Series

1.1) General Information

Owing to change of supplier from the new 3-way solenoid valve (part no. 874313) an adapted wiring harness and an airbox part no. 667574 have been introduced.

The new 3-way solenoid valve has been already installed on the following engines:

- 914 F as of S/N 4,420.710
- 914 UL as of S/N 4,419.744

1.1.1) Interchangeability of parts

The current 3-way solenoid valve part no. 874310 is available anymore only in limited number of items. Particularly for repair, and exchange purposes the retrofit kit part no. 881040 is provided.

◆ NOTE: If replacement of wiring harness part no. 966490 is necessary the 3-way solenoid valve must be also replaced.

Accessories and attachment of the 3-way solenoid valve could differ because of the possible variants of the airbox.

1.1.2) Disassembly and assembly

See the latest Maintenance Manual 914.

2.) Introduction of a new pressure sensor part no. 274051 for ROTAX® 914 Series

2.1) General Information

Due to the termination of production of the ambient pressure sensor (part no. 966507) a new ambient pressure sensor part no. 274051 has been introduced. The new ambient pressure sensor is of different size and also has a different connector. The connection for the wiring harness had to be changed.

Pressure sensor and wiring harness have already been installed on the following engines:

- 914 F as of S/N 4,420.863
- 914 UL as of S/N 6,773.116

2.1.1) Interchangeability of parts

The current pressure sensor part no. 966507 is of limited availability.

Fig No.	New p/n	Qty/ engine	Decription	Old part no.	Application
1	274051	1	pressure sensor	966507	ambient pressure
3	666012	1	adapter cable	-	wiring harness
4	924990	1	bracket	-	pressure sensor

◆ NOTE: If replacement of wiring harness part no. 966493 is necessary the pressure sensor and the bracket must be also replaced.

2.1.2) Disassembly and/ or new assembly

See Fig. 1 and 2.

1. Disconnect the pressure sensor (2) from the wiring harness.
2. Connect adapter cable (3) to wiring harness and to the new pressure sensor (1).
3. Install bracket (4) onto pressure sensor.

■ CAUTION: Route all wiring as such that there will be no sharp bends or chafing.


4. Position adapter cable and secure with cable binders (5).

2.2) Summary

The instructions have to be conducted accordingly.

2.3) Illustration

the following drawings should convey additional information:



3.) Introduction of a new FLYdat part no. 886858 for ROTAX® 912/914 Series

3.1) General Information

In the course of continuous development a new FLYdat part no. 886858 has been introduced, which simplifies data selections, because the new FLYdat operates via USB (own power supply).

3.1.1) Interchangeability of parts


At replacement take care of the following:


Take care of the respective oil pressure sensor! See also 79-00-00 sec. 1.3).


- ◆ NOTES: For more information, please contact an authorized distributor or Service Center for ROTAX® aircraft engines.

part no. overview:

The following tables offer additional information about characteristics of the different versions.

Model 1993	FLYdat part no. 886855 German, 886856 English
Characteristics	- 2 different front panels (German and English) - Service messages can only be reset by a ROTAX® authorized distributor - External warning lamp - Jack plug
Software	- Read out of data via RDAT part no. 886980 (no direct software for the PC) or - FLYdat monitoring device part no. 891315 (Windows system software)
	

Model 2004	FLYdat part no. 886857
Characteristics	- 1 version (English) - consistent design of the front panel - Button to reset the service messages - Warning lamp with display in case of exceeding maximum permissible value - Jack plug
Software	- Configuration of the FLYdat via PC - RS232 interface to the PC - Read out via PC (voltage of min. 10V necessary) - Windows system software - Firmware Update possible
	

Model 2008	FLYdat part no. 886858
Characteristics	- 1 version (English) - Button to reset the service messages - Warning lamp with display in case of exceeding maximum threshold - USB connection
Software	- USB Type A-interface to the PC (read out and configuration with Standard USB connecting cable possible) - Power supply via USB connection - Windows system software - Firmware update possible
08497  The image shows a black rectangular digital display unit. At the top, there are four labels: 'RPM 1/min', 'EGT/PTO °C', 'CHT °C', and 'OIL TEMP °C'. Below these is a large white rectangular display area. To the right of the display area is the 'FLYdat ROTAX' logo. Below the display area, there are four more labels: 'x 0,1h HOURS', '°C EGT/MAG', 'EGT display LEFT-RIGHT', and '0,1 bar OIL PRESS'. On the right side of the unit, there are two circular ports and a small square button.	

SECTION 78-00-00

1) Introduction of new exhaust bends an exhaust manifold on ROTAX® 914

1.1) General Information

(see fig. 1 to 2)

Owing to continuous further development, the exhaust bends were slightly re-worked. The couplings were optimized for their position.

- Position of the EGT connections (6) to the exhaust bends for cylinders 3 and 4 were routed such that installation of the new drip trays is possible.

The new exhaust bends and the new exhaust manifold have already been built into all of the following engines:

- 914 F as of S/N 4,420.364
- 914 UL as of S/N 4,418.248


parts requirement:

Fig item no	New part no	Qty per engine	Description	Old part no	application
1	979425	1	exhaust bend assy cyl. 1	979420/421/422	ROTAX® 914
2	979435	1	exhaust bend assy cyl. 2	979430/431/432	ROTAX® 914
3	979445	1	exhaust bend assy cyl. 3	979440/441/442	ROTAX® 914
4	979455	1	exhaust bend assy cyl. 4	979450/451/452	ROTAX® 914
5	979413	1	exhaust manifold	979411	ROTAX® 914


◆ NOTE: If replacement of any single old part number is necessary, you must replace it with the same old part number. If the old part number is not available, the **entire** assembly including all 4 pipes and manifold must be replaced with new part numbers. New style pipes and manifold are not interchangeable with old style.

1.2) Illustration

the following drawings should convey additional information:



new Version



1.) Introduction of a new oil pressure sensor for ROTAX® 912/914 Series**1.1) new oil pressure sensor part no. 456180**

(see fig. 1, 2, 3 and 4)

In the course of further development and standardization a new oil pressure sensor part no. 456180 has been introduced.

The new oil pressure sensor has been already installed on the following engines:

- 912 A up to S/N 4,410.959 inclusive
- 912 F up to S/N 4,413.009 inclusive
- 912 S up to S/N 4,924.446 inclusive
- 912 UL up to S/N 6,770.766 inclusive
- 912 ULS up to S/N 6,780.435 inclusive
- 914 F up to S/N 4,421.150 inclusive
- 914 UL up to S/N 7,682.317 inclusive

1.1.1) Interchangeability of parts

The oil pressure sensor part no. 956413 can no longer supplied and has been replaced by part no. 456180.

parts requirement:

Fig item no	New part no	Qty per engine	Description	Old part no	application
1	456180	1	oil pressure sensor	956413	oil pump
-	881302	1	connector set OPS and MAPS	-	oil pressure sensor
	or				
-	864250	1	oil pressure sensor wire assy.	-	oil pressure sensor
	686250*	1	oil pump housing with sensor	-	lubrication system

* Oil pump body with mounted sensor for easy retrofit if a rework of the oil pump housing is necessary.

1.1.2) Special tooling/lubricant-/adhesives-/sealing compound - Price and availability

Price and availability will be supplied on request by ROTAX® Authorized Distributors or their Service Centers.

parts requirement:

Fig item no	New part no	Qty per engine	Description	Old part no	application
-		1	crimp tool Delphi (manufacturer no. 12155975)	-	connector set OPS and MAPS assy.
-		1	thread tap M10x1	-	oil pump housing

1.2) Retrofitting and/or new reinstallation

- location: oil pump housing
- wiring connection for instrument:
(see fig. 3)

In contrary to the oil pressure sensor part no. 956413 the new oil pressure sensor part no. 456180 is equipped with a connector. As output signal the 2-wire version (4 to 20 mA) is available. **Oil pressure sensor PIN A** (connector housing PIN 1) is not connected and has no function.

■ **CAUTION:** To prevent the ingress of dampness into the connector housing, the free hole in the connector housing has to be closed with LOCTITE 5910, Silicone adhesive or similar.

Oil pressure sensor PIN B (connector housing PIN 2) has to be connected to the positive bus via a fuse or circuit breaker (the **Red** lead from the current oil pressure sensor). **Oil pressure sensor PIN C** (output signal) (connector housing PIN 3) has to be connected directly to the indicating instrument. For connection to the indicating instrument a connector set part no. 881302 or oil pressure sensor wire assy. part no. 864250 is available.

- ◆ **NOTE:** The sensor cable can be modified in its length according to the installation situation, e.g. shortened or extended. For extension an appropriate cable (Ölflex® Heat 260 MC 2x 0.5 mm² (AWG 20) or equivalent) can be used. A resistance cable or similar is not necessary.
- wire gauge: stranded wire, 0.5 mm² (AWG 20)

- operating temperature range:

min.: - 25 °C (-13 °F)

max.: + 125 °C (+ 257 °F)

- **CAUTION:** The sensor characteristic has been determined, and is effective at the following conditions only (see fig. 1).

ambient temperature: 20 °C (68 °F)

tolerance: ± 4%

- tightening torque: 15 Nm (98 in.lb) and LOCTITE 243

1.2.1) Replacement of the current oil pressure sensor by part no. 456180

Parts requirement: oil pressure sensor part no. 456180 and oil pressure cable assy. part no. 864250.

- **CAUTION:** Take care which oil pump housing is mounted. The part number is shown on the housing.

Oil pump housing part no. 911815 and part no. 911810

1. Remove the oil pressure sensor part no. 956413.
2. Install new oil pressure sensor part no. 456180 with LOCTITE 243.

Tightening torque 15 Nm (98 in.lb)

Oil pump housing part no. 811809

New oil pressure sensor part no. 456180 cannot be installed. Oil pump housing must be replaced or the threads must be recut.

1. Remove the oil pump housing in accordance with the relevant Maintenance Manual (Heavy).

Option A: Replace oil pump housing

Replace oil pump housing.

Option B: Rework of the oil pump housing

Recut threads with M10x1 thread tap.

- **CAUTION:** Clean the thread completely from swarf.

2. Install the oil pump housing in accordance with the relevant Maintenance Manual (Heavy).

3. Install new oil pressure sensor part no. 456180 with LOCTITE 243.

Tightening torque 15 Nm (98 in.lb).

- ▲ **WARNING:** Certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer.

1.2) Resistance type instruments

- The instruments need a separate power supply for the electric oil pressure sensor (part no. 956413 type: Honeywell) as mentioned previously.

- ◆ **NOTE:** Due to a configuration of the electric oil pressure sensor are already displayed on the ground approx. 0.2 bar (3 psi) (depending on the sea level and ambient pressure). Suitable instruments are offered by various instrument manufacturers (e.g. ROAD or Aviasport).

- ▲ **WARNING:** Certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer.

1.3) ROTAX[®] Flydat

- ◆ **NOTE:** Due to a configuration of the electric oil pressure sensor on the ground are already about approx. 0.2 bar (3 psi) (depending on the sea level and ambient pressure) displayed.

1.3.1) ROTAX[®] Flydat part no. 886858

- The ROTAX[®] Flydat part no. 886858 has already been prepared for the electric oil pressure sensor concerning its hardware and software.

- ◆ **NOTE:** For more information, please contact an authorized distributor or Service Center for ROTAX[®] aircraft engines.

1.3.2) ROTAX[®] Flydat part no. 886857

- For the ROTAX[®] Flydat part no. 886857 a retrofit kit for the electric oil pressure sensor is offered.

- ◆ **NOTE:** For more information, please contact an authorized distributor or Service Center for ROTAX[®] aircraft engines.

1.3.3) old models of ROTAX® Flydat

- For older ROTAX® Flydat models as e.g. part no. 886856/886855 a retrofit is not possible.

1.4) Illustration

the following sensor characteristic and drawings should convey additional information:






fig. 2


09489

1 oil pressure sensor

oil pressure sensor part no. 456180



	PIN	2 wire 4..20 mA
	A	n.a.
	B	8...28V DC
	C	OUT/GND



* resistor is part of the retrofit kit for Flydat part no. 886857. See also 1.3.2.

08446

fig. 4

2.) Introduction of a new oil filter part no. 825012

2.1) General Information

In the course of continuous development a new oil filter has been introduced.
In this connection the following modifications became necessary:

- installation height of oil filter (height increased by 3,5 mm/0,138 in.)

The new oil filter has already been installed on the following engines:

- 912 A as of S/N 4,410.892
- 912 F as of S/N 4,412.988
- 912 S as of S/N 4,924.119
- 912 UL as of S/N 6,770.210
- 912 ULS as of S/N 6,777.866
- 914 F as of S/N 4,420.994
- 914 UL as of S/N 6,774.303

parts requirement:


Fig item no	New part no	Qty per engine	Description	Old part no	application
	825012	1	oil filter	825706	lubrication system

2.3) Removal and installation

- see latest Maintenance Manual (Line).

2.4) Illustration

the following drawings should convey additional information.



- 1 oil filter
- 2 flange gasket

06297
fig. 5

NOTES